

Additional equipment

UNIVERSAL REMOTE



L A S E R W A R




Content

Getting started

1. Introduction
2. Description

Playing with Universal Remote

3. Switching on/off
 4. Device settings
 5. Operation
- 

Getting started

1. Introduction

Congratulations having purchased Universal Remote. Your time in laser tag is our TOP priority. We attempt to keep the game easy, fun, and modern. The device is functional right out of the box.

If you are just getting to know laser tag equipment, the instructions will help you learn quickly and start the game. If you're a seasoned user, go through all of the information and make sure you didn't miss anything from the possibilities provided by Universal Remote.

2. Description


The device is the most advanced in the LASERWAR remote control line. It has eight commands and is designed to interact with laser tag equipment.

The remote control is an AA battery-powered device featuring front-panel control keys, an IR receiver/emitter, and a micro-USB port for charging or connection with a PC.

Playing with Universal Remote

3. Switching on/off

There is no need to turn off the device because it responds to all button presses and immediately plays the desired command. To get started, there is only one requirement: the device must have batteries.



4. Device settings

Each button on the front of the remote control is labeled with the name of the command it controls. The remote control has two modes: basic commands (shown in white) and Shift mode commands (indicated in red).

Initially you will be able to start a new game, change the player's color, double hp, kill the player. If these settings are not enough for you, go to Shift. To enter the mode, press and hold Button 1 for five seconds. The entry is indicated by short LED flashes. The assignment of the buttons changes according to the settings.

The mode is also exited by pressing Button 1 for five sec. If the user takes no action, the device automatically exits after 4 min. and switches to the low power mode.


The following commands are available in this mode: Immediate New Game, shot power 49/99%, Zombie Apocalypse scenario, Last Hero scenario.

Using LASERWAR Configurator, you can assign the functions you want instead of the standard ones.

Connect the USB base to a PC and enter the admin mode (press the button on the back of the body with a simple pin or toothpick, for example). Press the RECORD button after making the necessary changes to the default settings.

5. Operation

On the remote control, there are only four buttons used to operate and change settings. Universal Remote may be used to play any scenario. By default, there are two of them, which are switched with Buttons 3,4 in the Shift mode.



**In case you have any questions left, please,
get in touch with our tech support
department:**

Technical support

Phone: +371 26763197

Email: help@laserwar.com

WhatsApp: +371 26763197

Viber: +371 26763197

Skype: [help@laserwar.com](https://www.skype.com/people/help@laserwar.com)

Official website:
www.laserwar.com



L A S E R W A R